



FOR USE WITH TRED-MOR® MODULAR PVI®

ADHERING CUSHION TO SUBSTRATE

Dubl-STIK® System

Pressure-Sensitive Adhesive:

The use of a pressure-sensitive adhesive, applied with a 1/16'' width x 1/32'' depth x 1/32'' spacing notched trowel to ensure evenness of the application, is suggested for attaching the cushion to the floor. A short-nap paint roller or the back of a trowel can also be used, but unevenness of application using these techniques could lead to difficulty in the removal of the installation. Failure to allow the proper curing time for the adhesive prior to installing the cushion could also lead to difficulty of removal. **Consult your adhesive manufacturer for specific instructions.**

Multi-Purpose, PREMIUM-Quality Carpet Adhesive:

A premium-quality, multi-purpose adhesive can be used to install cushion to the substrate, but it is <u>not recommended</u> because the removal of the installation will be extremely difficult.

Singl-STIK[™] System*

Because of the weight and density of Tred-MOR Carpet Tile, many residential and light commercial applications may be installed using the Singl-STIK System (loose lay). Simply unroll the rolls and butt the seams tight. (DO NOT FLIP CUSHION – floor side is down when unrolled.) Seams must be taped with a good-quality duct tape to ensure no gapping. Always offset the cushion and carpet tile seams to avoid separation of the complete system. Follow the carpet manufacturer's guidelines for installation of their specific product and adhesive types.

ADHERING CARPET TILE TO CUSHION

Dubl-STIK® and Singl-STIK® System®

The varieties of backings available are numerous and constantly changing; it is important that you check for each installation. Optimum adhesion of the carpet tile to cushion is attained when the correct amount of adhesive is used. It is important to follow your adhesive maunfacturer's guidelines for spread rates, open time, and trowel size. Leggett & Platt Flooring Products recommends the use of a 1/16" x 1/16" x 1/16" trowel for the installation of all carpet tile to the cushion. Proper open time of the adhesive (pressure-sensitive) will lead to a releasable installation of carpet tile to cushion and cushion to substrate, making repairs and future tear-out easier.

Also check for recommendations on rolling the product. The adhesive and carpet tile manufacturers may recommend that after sufficent open time, the carpet tile should be pressed down into the adhesive using a roller, or even a section of the cushion tube.

*not recommended for areas with heavy continuous rolling-wheel traffic

Leggett & Platt Flooring Products does not warranty (either expressed or implied) the performance of any adhesive supplied by third parties.

RECOMMENDED ADHESIVES

Tred-MOR recommends the use of Taylor Versatile pressure-sensitive adhesive to apply the cushion to the substrate and Taylor Agile multi-purpose adhesive to apply the carpet to the cushion. For hard-surface products, we recommend the Taylor Versatile pressure-sensitive adhesive.

Tred-MOR offers these adhesives for purchase. Contact your representative for details.

GENERAL ADHESIVE USE

Adhesives suitable for use with Tred-MOR Dubl-STIK installations can also be obtained from other adhesive manufacturers. Each manufacturer has its own specific warranties and recommendations for use with Tred-MOR. Consult the manufacturer of your choice for their warranties, recommended products, and installation instructions.

NAME	PHONE NO.
AAT	800-228-4583
APAC	800-747-2722
Ardex	888-512-7339
Bostik	800-726-7845
Capitol	888-875-5087
HP Fuller	800-621-0220
Mapei	800-992-6273
Milliken	800-241-4826
Royal	800-763-7272
Roberts/QEP	800-423-6545
W.W. Henry	888-512-7339

Tred-MOR®

Floor Cushion and Acoustic Systems by SCI®, a Leggett & Platt company

FOR MORE INFORMATION: PHONE: 1-800-435-4062 REVISED 07-12-21